

Configuring Wireless 2.4GHz

Figure 7-16 Wireless (2.4GHz) page

Status

Network

LAN

LAN_IPv6

WAN

WAN_DHCP

Wireless (2.4GHz)

Wireless (5GHz)

Wireless Schedule

IP Routing

DNS

TR-069

GRE Tunnel

US Classifier

QoS Config

Security

Application

Maintenance

RG Troubleshooting

GPON Home Gateway

Logout

Network>Wireless (2.4GHz)

Enable☒

Mode

auto(b/g/n)

Bandwidth

20MHz

Channel

Auto

Transmitting Power

100%

WMM

Enable

Total MAX Users

32

SSID Configuration

SSID Select

SSID1

SSID Name

ALJIN-0E37-bandsteering

Enable SSID

Enable

SSID Broadcast

Enable

Port Mode

Route

Isolation

Disable

MAX Users

32

Encryption Mode

WPA/WPA2 Personal

WPA Version

WPA/WPA2

WPA Encryption Mode

TKIP/AES

WPA Key

1234567890

☒ Show password

Enable WPS

Disable

Domain Grouping

☐ Enable

Save

Refresh

Table 7-13 Wireless (2.4GHz) parameters

Field	Description
Enable	Select this checkbox to enable Wi-Fi.
Mode	Select a Wi-Fi mode from the list: • auto (b/g/n) • b • g • n • b/g • g/n
Bandwidth	Select from: • 20 MHz • 40 MHz • 20/40 MHz
Channel	Select a channel from the list or select Auto to have the channel automatically assigned.
Transmitting Power	Select a percentage for the transmitting power from the list: • Low (25%) • Medium (50%) • High (75%) • Maximum (100%)
WMM	Select Enable or Disable from the list to enable or disable WiFi multimedia.
Total MAX Users	Enter the number of total MAX users.
SSID Configuration	
SSID Select	Select the SSID from the list.
SSID Name	Enter the SSID name.
Enable SSID	Enable or disable SSID from this list.
SSID Broadcast	Enable or disable SSID broadcast from this list.
Port Mode	Select a port mode from the list. Route is the default.
Isolation	Select Enable or Disable from this list.
MAX Users	Enter the number of MAX users.
Encryption Mode	Select an encryption mode from the list: • OPEN • WEP • WPA/WPA2 Personal • WPA/WPA2 Enterprise

Field	Description
WPA Version	Select a WPA version from the list: • WPA1 • WPA2 • WPA1/WPA2
WPA Encryption Mode	Select a WPA encryption mode from the list: • AES • TKIP/AES
WPA Key	Enter the WPA key.
Enable WPS	Select Enable or Disable from this list.
WPS Mode	Select a WPS mode from the list: PBC (Push Button Connect) or PIN (Personal Identification Number).
Domain Grouping	Select this checkbox to enable domain grouping. When enabled the fields Domain Name , WAN Interface , Number of IP , and LAN List become visible. To know more about configuring the fields, refer to the Table 7-14: "Wireless (5GHz) parameters" (p. 103).

3 _____

If you have enabled and configured WPS, click **WPS connect**.

4 _____

Click **Save**.

Configuring Wireless 5GHz

Figure 7-17 Wireless (5GHz) page

GPON Home Gateway

Logout

Status

Network

LAN

LAN_IPv6

WAN

WAN DHCP

Wireless (2.4GHz)

Wireless (5GHz)

Wireless Schedule

IP Routing

DNS

TR-069

GRE Tunnel

US Classifier

QoS Config

Security

Application

Maintenance

RG Troubleshooting

Network>Wireless (5GHz)

Enable

☒

Bandwidth

80MHz

Channel

Auto

Transmitting Power

100%

WMM

Enable

Enable MU-MIMO

Disable

Total MAX Users

32

SSID Configuration

SSID Select

SSID5

SSID Name

ALHN-0E37-bandsteering

Enable SSID

Enable

SSID Broadcast

Enable

Port Mode

Route

Isolation

Disable

MAX Users

32

Encryption Mode

WPA2+WPA

WPA Key

1234567890

☒ Show password

Enable WPS

Disable

Domain Grouping

☐ Enable

Save

Refresh

Table 7-14 Wireless (5GHz) parameters

Field	Description
Enable	Select this checkbox to enable Wi-Fi.
Bandwidth	Select from: • 20 MHz • 40 MHz • 80 MHz
Channel	Select a channel from the list or select Auto to have the channel automatically assigned.
Transmitting Power	Select a percentage for the transmitting power from the list: • Low (25%) • Medium (50%) • High (75%) • Maximum (100%)
WMM	Select Enable or Disable from the list to enable or disable WiFi multimedia.
Total MAX Users	Enter the total number of MAX users.
SSID Configuration	
SSID Select	Select the SSID from the list.
SSID Name	Change the name of the selected SSID.
Enable SSID	Select Enable or Disable from this list.
SSID Broadcast	Select Enable or Disable SSID broadcast from this list.
Port Mode	Select a port mode from the list. Route is the default.
Isolation	Select Enable or Disable from this list.
MAX Users	Enter the number of MAX users.
Encryption Mode	Select an encryption mode from the list: • OPEN • WPA/WPA2 Personal • WPA/WPA2 Enterprise
WPA Key	Enter the WPA key.
Enable WPS	Select Enable or Disable WPS from this list.
WPS Mode	Select a WPS mode from the list: PBC (Push Button Connect) or PIN (Personal Identification Number).
Domain Grouping	
Domain Grouping	Select this checkbox to enable domain grouping. The fields Domain Name , Create One New Domain , WAN Interface , Number of IPs and LAN List are available when the Domain Grouping field is enabled.
Domain Name	Select a domain name from the list.
Create One New Domain	Select this checkbox to create a new domain.
WAN Interface	Select a WAN interface from the list.

Field	Description
Number of IP	Select the number of IPs connected to the domain.
LAN List	Select one or more checkboxes.

3 _____

If you have enabled and configured WPS, click **WPS connect**.

4 _____

Click **Save**.